

Cresta OptiTop for Cresta and Cresta Basic turbo units

Guidance

APPLICATIONS AND WARNINGS

This device is designed solely for respiratory protection with the filtering units "Cresta" and "Cresta Basic" in the hood mode and not in potentially explosive atmospheres. These instructions must be read in conjunction with those of the filtering unit and with the hood for instructions for use "OptimAir 3000 OptiTop". Depending on the filters fitted to the Cresta/Cresta Basic the following classes with regard to EN 12941 will be met: -

Filter	Class according to EN 12941
P 999	TH 3 P
793 with filter receptacle	TH 3 P
87 A	TH 3 A2
87 ABEK2	TH 3 A1 B2 E2K2
89 A/St	TH 3 A2 P-SL
89 B/St	TH 3 A2B2 P-SL
89 K/St	TH 3 K2 P-SL
89 ABEK2 Hg/St	TH 3 A2B2E2K2 P-SL
89 Hg/St	TH 3 Hg P-SL
89 Reaktor B/St	TH 3 A2 B2 E1 P-SL
89 Reaktor St	TH 3 P-SL

For Statutory Warnings, Fitting, Cleaning, Storage see instructions for use "OptimAir 3000 OptiTop". Visor and helmet statutory markings see table 1, Visors and 2, Helmets, below

Spares and Accessories:

See instructions for use "OptimAir 3000 OptiTop" for spare hoods and helmets. Spares specifically for use with the Cresta/ Cresta Basic are listed below:

Cresta OptiTop	Part No. 10057101
EN connector M32 x 1,5, assy	Part No. 10019466
Spare hose assembly (c/w RD 40 connector and clamp band)	Part No. B1476002
SEAL KIT	Part No. 10014460
CHINSTRAP(PK10)	Part No. B0258213

(1)

CE  1 B EN 166 3 -B		
CE	UK	D
	Trade mark	Schutzmarke
1	Optical class	Optische Klasse
B	Ocular impact	Augenfällige Auswirkung
EN 166	Standard	EN Norm
3	Liquid splash	Flüssigkeitsspritzer
-B	Frame impact	Stoß mit mittlerer Energie

(2)

440V AC	SHORT TERM ELECTRICAL CONTACT	Elektrische Isolierung
-30°C	LOW TEMPERATURE LIMIT	Minimale Temperatur
LD	PROGRESSIVE LATERAL FORCES	Seitliche Verformung

NOTIFIED BODY No. 0194 INSPEC CERTIFICATION LTD. UPPER WINGBURY COURTYARD. WINGRAVE. AYLESBURY. BUCKS. HP22 4LW.



Cresta OptiTop für Cresta und Cresta Basic

Zusatzinformation zur Gebrauchsanweisung

Der Atemanschluss Cresta OptiTop ist nur in Verbindung mit dem Gebläsegerät Cresta oder Cresta Basic im Haubenmodus zu betreiben und darf nicht in explosiver Atmosphäre verwendet werden. Die entsprechenden Gebrauchsanleitungen (Gebläsegerät Cresta oder Cresta Basic und dem Atemanschluss) müssen gelesen werden.

Abhängig von den verwendeten Filtern werden die in der Tabelle angegebenen Schutzklassen erreicht:

Filter	Schutzklasse gemäß EN 12941
P 999	TH 3 P
793 mit Filtergehäuse	TH 3 P
87 A	TH 3 A2
87 ABEK2	TH 3 A1 B2 E2K2
89 A/St	TH 3 A2 P-SL
89 B/St	TH 3 A2B2 P-SL
89 K/St	TH 3 K2 P-SL
89 ABEK2 Hg/St	TH 3 A2B2E2K2 P-SL
89 Hg/St	TH 3 Hg P-SL
89 Reaktor B/St	TH 3 A2 B2 E1 P-SL
89 Reaktor St	TH 3 P-SL

Warnhinweise, Verwendung, Reinigung und Lagerung des Atemanschlusses siehe Gebrauchsanleitung OptimAir 3000 OptiTop. Kennzeichnung der Sichtscheibe und des Helmes siehe Tabelle 1 und Tabelle 2.

Ersatzteile und Zubehör:

Siehe Gebrauchsanleitung OptimAir 3000 OptiTop für Ersatzhauben und Helme. Ersatzteile speziell für die Verwendung mit Cresta oder Cresta Basic:

Cresta OptiTop	10057101
Rundgewindeanschluss M32 x 1,5, kpl	10019466
Ersatzschlauch (Rd 40 Anschluss und Schelle)	B1476002
Dichtungskit	10014460
Kinnriemen (Pg 10 St)	B0258213